

Anziehvorschrift für Zylinderkopf		153.002				
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a PSA, Fiat, Ford, Volvo				
Instructions de serrage pour culasse						
Prescripciones de apriete para culatas						
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
 267.550 M 12x1,5x126						
Anziehen/ Tightening/ Serrage/ Apriete	* 20 Nm 60 Nm 60 Nm 110° 110° ☐ 20 Nm 60 Nm 110° 110°	PSA DW10ATED4	* 20 Nm 60 Nm 20 Nm 60 Nm 110° 110° ☐ 20 Nm 60 Nm 110° 110°	PSA DW12TED4	* 30 Nm 60 Nm 220° ➤ 220°	Fiat, Ford, Volvo
Zeichenerklärung / Explanations / Explication / Explicacion						
* ★ ☐ ● ➤	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos		
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)		
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo		
	Setzzeit	relaxation time	durée de tassement	tiempo de espera		
	Drehwinkel	torque angle	angle de serrage	ángulo de giro		
Motortyp / Engine type / Type de moteur / Tipo de motor						
✚ 1,3 mm, Ø 86 mm, 2 Löcher/holes/trous/agujeros						
Mot.: G6DA, G6DB, G6DC, G6DD, G6DE, G6DF, AZWA QXWA, QXWB, DW10ATED4, DW10BTED4, DW12TED4 RHR, RHK/DW10UTED4, D4202T/T2						
Focus, C-Max / 307, 406, 407, 607, 807 V40II, V50 / C4, C5, C8						
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*153.002*			