


Anziehvorschrift für Zylinderkopf	867.700	
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	Renault, Nissan, Opel
		Das Original

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



481.900
M12x1,5x135

Anziehen/	*	Pos 1-10: 5 Nm
Tightening/		Pos 1-10: 30 Nm
Serrage/	➤	Pos 1-10: 150° ±3°
Apriete	➤	Pos 1-10: 150° ±3

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Mot: R9M & R9N401

1.6 ltr 66-118 kW (90-160 PS)

Renault Scénic III, Grand Scénic, Megane III

Espace, Fluence

Nissan Qashqai, X-Trail

Opel Vivaro

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

867.700