

GB

Trailer/ Cable bundle

Parts list	Socket with cables	1 pc.
	PVC clips	6 pcs.
	Screw M6x35	3 pcs.
	Nut	3 pcs.

I. Standardised connection

Colour	Cables	Functions
Yellow	1/L	Left-turn indicator in the rear lamp
Blue	2/54G	Rear fog lamp
White	3 31	Grounding
Green	4/R	Right-turn indicator in the rear lamp
Brown	5/58R	Right side rear light, license plate light
Red	6 54	Brake light
Black	7/58L	Left side rear light

Warning: Unpack the e-set and check its contents against the parts list.

In case of any kind of computer controlled vehicles, sound synthesis or special accessories take the special cable bundle into consideration.

We decline all the responsibilities concerning improper usage.

II. **Some regulations**

1.) Check the cabling and the respective functions according to the colours of the wires. Reinstall the covers of the cable and do not forget to replace the PVC insulation.

2.) Motor vehicle

Once having the input zones of the cable identified at the rear lamps, divide the different wires according to their functions. Drill a hole 22mm through the bottom plate of the boot if necessary, so that the cable bundle can be lead through.

3.) After having installation completed

Connect the male of the trailer's (caravan's) socket to the vehicle, then check for proper function (turn indicator light, brake light, rear light and fog light).

